



# POWerview RESET INSTRUCTIONS

1. PRESS AND HOLD CENTER/STOP BUTTON ON PEBBLE UNTIL IT BLINKS
2. CHOOSE A SOURCE ON THE PEBBLE REMOTE (1, 2 AND 3 ETC.)
3. THIS STEP IS CRITICAL AND MUST BE DONE SIMULTANEOUSLY: PRESS PROGRAM BUTTON SHADE THEN PRESS OPEN ON PEBBLE REMOTE
4. THE SHADES SHOULD THEN JOG UP AND DOWN! IF IT DOES JOG- PROCEED TO STEP 5. IF IT DOES NOT, REPEAT ALL PRIOR STEPS
5. PRESS AND HOLD CENTER BUTTON TO GET IT OUT OF PROGRAM MODE

**YOUR POWerview SHADE HAS  
SUCCESSFULLY BEEN RESET!**

If the reset was unsuccessful please contact the showroom to schedule an appointment